

# Extend the Life of Your Car with Mechanical Breakdown Protection



Protect your vehicle far beyond the manufacturer's warranty with Mechanical Breakdown Protection from Mercury.

## AVOID UNEXPECTED COSTLY REPAIRS


Mercury's Mechanical Breakdown Protection Plans extend coverage to virtually all mechanical and electrical components of your vehicle. They are available for both new and pre-owned vehicles, and coverage is transferrable if you sell your vehicle before your agreement expires providing added resale value.

## MERCURY MAKES IT EASY FOR YOU!

- Repairs can be done at any licensed U.S. or Canadian repair facility
- No limit to the number of claims and one deductible per visit
- All claims are handled by Mercury, not a third party administrator, with direct payments to repair facilities
- Enjoy additional savings up to 50% or more off manufacturer extended warranties

	Bronze	Silver	Gold	Platinum
Hardware				
Audio Center				
Air Conditioning				
Fuel				
Brakes				
Suspension				
Electrical				
Steering				
Drive Axle				
Transmission & Transfer Case				
Engine				

## AVERAGE REPAIR ESTIMATES\*



\* Average repair estimates based on Mercury's internal data adjusting claims for 2008.

## COVERAGE BENEFITS

**24-Hour Roadside Assistance.** In the event your vehicle is disabled during the term of your coverage, towing and other roadside services are provided.

**Rental Vehicle Assistance.** In the event of a covered Mechanical Breakdown during the term of your contract, you will be covered for alternate transportation expenses according to the schedule in your agreement.\*

**Tire Protection.** If the tires on your vehicle are damaged during their normal life by glass, nails or other road hazards, they will be repaired or replaced.\*

**Trip Interruption.** You can be reimbursed for meals and lodging up to three days if you are stranded because of a covered breakdown more than 100 miles away from your home.

**Want Maximum Protection? Go Platinum!**

Mercury's **premium Platinum Protection Plan** gives you complete peace of mind, while also **increasing your vehicle's resale value!**

Your Mercury Agent



Phone:  
Fax:

# Extend the Life of Your Car with Mechanical Breakdown Protection














## Choose your plan.










**Platinum Protection** includes all components listed in Gold, Silver and Bronze, plus extended coverage for virtually all of your vehicle's mechanical and electrical components\*




**Gold Protection** includes all components listed in Silver and Bronze, plus the following:

-  **ENGINE:** Exhaust manifold • Radiator • Electric fan motor • Water pump housing • Belt tensioner • Engine thermostat • Hot water valve.
-  **TRANSMISSION AND TRANSFER CASE:** Electronic shift control: processor, sensor • Four wheel drive actuator.
-  **DRIVE AXLE:** Differential cover.
-  **STEERING:** Dampener • Tie rods • Tie rod ends • Steering wheel • Tilt wheel mechanism • Rear wheel steering: control valve and sensor, control unit, shaft and couplings, power cylinder(s), oil pump, stepper motor, rack assembly.
-  **BRAKE:** Combination valve • Accumulator • ABS: booster pump, control processor, control sensors, control solenoids, modulator valve, valve and accumulator • Brake calipers • Wheel cylinders.
-  **SUSPENSION:** Radius arm and bushing • Stabilizer bar, links and bushings • Strut bearings and bushings • Air suspension compressor • Suspension control computer • Suspension control solenoids • Height sensor • Mode selector switch.
-  **ELECTRICAL:** Electronic fuel injection: sensors, control units • Electronic spark timing control unit • Igniter • Horn and horn relay • Power antenna motor.
- Rear window: defogger unit, defrost grid • Electric power seat motor • Electric convertible top motor • Electric sunroof motor • Electric headlamp motor • Electronic instrument panel: control module, display • Engine wiring harness • Electronic traction control sensors and control module • Electronic suspension air compressor • Factory installed theft alarm system • Factory installed remote keyless entry transmitter/receiver • Inclinator • Illuminated vanity mirrors • Trip/mileage computer.
-  **FUEL SYSTEM:** Fuel injection pump • Diesel fuel injectors • Gasoline fuel injectors (for electrical failure only) • Vacuum pump.
-  **AIR CONDITIONING:** Pressure switches • Automatic temperature control selector head • Air ducts • Air registers • Control cables • Power module • Plenum doors • Vacuum motors • Heater core.
-  **AUDIO CENTER:** Factory installed entertainment chassis modules including: Radio • CD player • Magnetic tape player • Graphic equalizer (Limited to repair only, not replacement).
-  **HARDWARE:** Ashtrays • Door: latches, locks, hinges • Hood: latch release mechanism, struts, hinges, torsion bars • Ignition switch lock cylinder • Rear hatch struts • Seat tracks • Deck lid: latch/release, hinges, torsion bars • Power seat transmission • Window: crank handles, regulators • Wiper motor transmission • Altimeter • Compass • Glove box: lock, latch.

**Silver Protection** includes all components listed in Bronze, plus the following:

-  **ENGINE:** Engine oil pressure gauge • Radiator fan motor • Water pump and pulley • Fan clutch • Fan shroud • Radiator coolant recovery unit • Electric radiator fan motor relay/switch • Electric radiator fan motor sensor • Engine coolant temperature gauge.
-  **STEERING:** Gear housing/rack assembly and their internal components • Control valve and cylinder • Power cylinder assembly • Steering column shaft(s) and their couplings/bearings • Steering knuckle • Power steering pump, pulley, and mounting bracket • Pitman arm • Idler arm • Drag link • Steering column bearings.
-  **BRAKE:** Master cylinder • Power brake assist boosters • Backing plate assembly • Brake pedal assembly • Parking brake pedal • Parking brake cable • Parking brake release mechanism • Self adjusters • Brake lines & fittings.
-  **SUSPENSION:** Wheel bearings • Sway bar and its bushings and linkage • Upper and lower control arms • Control arm shafts and bushings • Upper and lower ball joints • Strut bar • Spindle and support.
-  **ELECTRICAL:** Alternator • Voltage regulator • Ignition coil • Electronic ignition: module, distributor • Throttle position sensor • Fuel control temperature sensor • Idle control actuator • Manifold vacuum sensor • Crankshaft position sensor • Camshaft position sensor • Alternator: pulley, mounting bracket • Igniter • Volt/amp gauge • Starter motor • Starter motor: drive, solenoid • Wiper motors • Manually operated electrical switches • Horn and horn relay • Electric window motors • Electric mirror motors • Cruise control: module, actuator • Electric door lock: relay, actuator • Electric trunk/tailgate/hatchback actuators • Backup light switch • Brake light switch • Door operated courtesy light switches • Neutral safety switch • Windshield washer pump • Cigarette lighter(s) • Auxiliary power point • Tachometer • Headlamp dimmer switch • Map lights • Clock.
-  **FUEL SYSTEM:** Fuel tank • Fuel pump • Accelerator pedal • Fuel pressure regulator • Fuel level sending unit • Accelerator pedal linkage • Fuel pressure sensor • Fuel pump relay • Fuel shutoff control • Fuel tank filler pipe • Metal fuel lines • Fuel gauge.
-  **AIR CONDITIONING:** Compressor • Accumulator/drier only in conjunction with compressor replacement • Condenser • Evaporator • Compressor clutch and coil • Compressor pulley and mounting bracket • Expansion valve • Orifice tube • Idler pulley and bearing • Manual temperature control selector head • Blower motor • Heater control valve • Idler pulley tensioner.

**Bronze Protection**

-  **ENGINE:** Cylinder block • Cylinder head(s) • Turbocharger/supercharger and their internal components • Mounts • Timing gears • Timing/balance shaft chain/belt, guides, tensioners, sprockets and cover • Flywheel/flex-plate • Harmonic balancer • Oil pan • Oil pump • Intake manifold • Valve cover(s) • Wastegate.
-  **TRANSMISSION AND TRANSFER CASE:** Transmission and transaxle cases and their internal components • Mounts • Torque converter • Vacuum modulator • Transmission oil cooler • Gear shift lever • Transmission shift linkage • Pan • Transfer case and all internal components.
-  **DRIVE AXLE:** Final drive and axle housings and their internal components • Axles • Axle shafts and bearings • Propeller shafts • Hubs • Constant velocity joints • Universal joints • Center bearings • Yokes • Hub bearings • Locking rings.

\* **COVERAGES AND EXCLUSIONS** — Seals and gaskets are included for all Platinum, Gold, and Silver Plan covered components. Fluids and filters are included in conjunction with a covered repair. Examples of parts not covered are: Non-Mechanical, Non-Electrical, Non-Pneumatic or Non-Hydraulic Components; Audio Speakers; Batteries; Bumpers; Cables; Chassis; Clamps; Fasteners; Convertible Tops and their mechanisms; Exhaust/EGR System; Air Pump and Catalytic Converter, PCV System; Fuel Vapor Recovery System; Glass; Hoses; Lines and Fittings; Mirrors; Manual Clutch Components; Passenger/Driver Restraint Systems; Seat Components; Secondary Ignition Components; Suspension Springs; Telephones; Torsion Bars; Wheels; Internet Computer; Telematic Services And Devices (i.e., Onstar); Navigation System; Video Components; Heads-Up Display; Night Vision Systems; Normal Maintenance and Service Items; Filters/Fluids/Lubricants/Refrigerants; Fuses; Lights/Bulbs/Lenses Assemblies; Wear Items; Accessory Drive Belts; Brake Pads/Shoes/Drums/Rotors; Shocks; Struts; Wiper Blades, and any component not supplied as original equipment by the vehicle manufacturer. We may use replacement components of a like kind and quality that may be rebuilt, remanufactured, or used. Refer to the contract for the conditions of coverage, exclusions and your duties during the term of the contract.